


HS-AS 螺柱

翅片安装螺柱



用于电机的翅片。

安装螺柱提供一个安全、永久或半永久的连接点。

零件号。

连接点1

连接点2

HS-AS040-40

1/4"-28 UNF母头

40 mm x 7 mm



HS-AS040-50

1/4"-28 UNF母头

50 mm x 7 mm



HS-AS105-1

1/4"-28 UNF母头

30 mm x 13 mm



HS-AS105-2

1/4"-28 UNF母头

50 mm x 13 mm



HS-AS105-3

1/4"-28 UNF母头

45 mm x 5 mm



HS-AS105-4

1/4"-28 UNF母头

25 mm x 5 mm

